

Parts list for B, C, D categories including B0104a, B0123, B0124a, B0431a, B0432a, C0107Dc, C0264, C0270c, C0271c, C0529Ac, C0601, C0601/1a, C0605, C0801Hc, D0602, D0807b.

E-Parts

Parts list for E categories including E0135-Bb, E0155a, E0159a, E0160b, E0161b, E0162a, E0163, E0164, E0165, E0166, E0167, E0175, E0168, E0169, E0170, E0171, E0176.

B, C, D-Parts

Parts list for B, C, D categories including B0104a, B0123, B0124a, B0431a, B0432a, C0107Dc, C0264, C0270c, C0271c, C0529Ac, C0601, C0601/1a, C0605, C0801Hc, D0602, D0807b.

E-Parts

Parts list for E categories including E0135-Bb, E0155a, E0159a, E0160b, E0161b, E0162a, E0163, E0164, E0165, E0166, E0167, E0175, E0168, E0169, E0170, E0171, E0176.

Parts list for E categories including E0174a, E0183a, E0210a, E0219b, E0221, E0238a, E0239b, E0240b, E0241b, E0242, E0319a, E0322a, E0517a, E0518a, E0519a, E0520a, E0545b, E0546b, E0548c, E0551, E0552, E0553, E0558, E0559, E0560, E0554, E0555, E0556, E0561, E0562, E0563, E0564, E0565, E0566, E0569.

Parts list for OPT categories including E0571, E0572, E0573, E0574, E0581, E0575, E0576, E0577, E0578, E0582, E0601a, E0601/1b, E0602a, E0602/1a, E0701b, E0705a, E0803a, E0806a, E0808b, E0813a, E0814a, E0825-Ba, E0829b, E0834a, E0835, E0903a, E1081W, E0571, E0572, E0573, E0574, E0581, E0575, E0576, E0577, E0578, E0582, E0601a, E0601/1b, E0602a, E0602/1a, E0701b, E0705a, E0803a, E0806a, E0808b, E0813a, E0814a, E0825-Ba, E0829b, E0834a, E0835, E0903a, E1081W.

Parts list for Not used in this kit categories including E1081Y, E1081B, E1084, E2115a, E2116, E2120a, E2121Bb, E2123a, E2124a, E2136, E2137, E2138, E2139b, E2142b, E2143b, E2143d, E2143e, E2146b, E2147b, E2148b, E2148d.

Parts list for OPT categories including E2149b, E2150b, E2153b, E2158b, E2161b, E2162b, E2163b, E2164b, E2165, E2166b, E2167b, E2168b, E2172, E2173a, E2149b, E2150b, E2153b, E2158b, E2161b, E2162b, E2163b, E2164b, E2165, E2166b, E2167b, E2168b, E2172, E2173a.

Parts list for OPT categories including E2174a, E2177a, E2178a, E2179a, E2182a, E2182A/B, E2182L, E2182R, E2182L, E2182R, E2186a, E2187a, E2188a, E2188L, E2188R, E2189a, E2189L, E2189R, E2230, E2231, E2232b, E2234b, E2235b, E2236b, E2237a, E2238b, E2174a, E2177a, E2178a, E2179a, E2182a, E2182A/B, E2182L, E2182R, E2186a, E2187a, E2188a, E2188L, E2188R, E2189a, E2189L, E2189R, E2230, E2231, E2232b, E2234b, E2235b, E2236b, E2237a, E2238b.

E2240b, E2241a, E2242b parts list with diagrams and quantities.

E2301b parts list with diagrams and quantities.

E2421b, E2422b, OPT parts list with diagrams and quantities.

E2568a, E2569b, E2571, OPT parts list with diagrams and quantities.

E2715a, E2716a, E2717a, E2718a parts list with diagrams and quantities.

H, T-Parts parts list with diagrams and quantities.

E2243a parts list with diagrams and quantities.

E2303b parts list with diagrams and quantities.

E2429a parts list with diagrams and quantities.

E2572b, E2573a, E2574b parts list with diagrams and quantities.

E2719a, E2720a, E2721a, E2722 parts list with diagrams and quantities.

H0274a, H0471a, H0855b, H0864-Ba parts list with diagrams and quantities.

E2245-B parts list with diagrams and quantities.

E2306b, E2309h, E2310b OPT parts list with diagrams and quantities.

E2430a, E2431a, OPT parts list with diagrams and quantities.

E2577a parts list with diagrams and quantities.

E2723a parts list with diagrams and quantities.

H0274a, H0471a, H0855b, H0864-Ba parts list with diagrams and quantities.

E2250b OPT parts list with diagrams and quantities.

E2314b, E2316a parts list with diagrams and quantities.

E2434a parts list with diagrams and quantities.

E2579a parts list with diagrams and quantities.

E2724, E2725 OPT parts list with diagrams and quantities.

H0274a, H0471a, H0855b, H0864-Ba parts list with diagrams and quantities.

E2260a, E2263b, E2264b parts list with diagrams and quantities.

E2319a, E2320a parts list with diagrams and quantities.

E2504b, E2505a, E2506a parts list with diagrams and quantities.

E2580 parts list with diagrams and quantities.

E2803b, E2804b parts list with diagrams and quantities.

H0274a, H0471a, H0855b, H0864-Ba parts list with diagrams and quantities.

E2265 parts list with diagrams and quantities.

E2321a, E2322a OPT parts list with diagrams and quantities.

E2507, E2510 OPT parts list with diagrams and quantities.

E2580 parts list with diagrams and quantities.

E2805b parts list with diagrams and quantities.

H0274a, H0471a, H0855b, H0864-Ba parts list with diagrams and quantities.

E2266 parts list with diagrams and quantities.

E2324 OPT, E2325 OPT, E2326 OPT parts list with diagrams and quantities.

E2515, E2516, E2517, E2518 OPT parts list with diagrams and quantities.

E2580 parts list with diagrams and quantities.

E2808a, E2809b parts list with diagrams and quantities.

H0274a, H0471a, H0855b, H0864-Ba parts list with diagrams and quantities.

E2267a OPT, E2268a parts list with diagrams and quantities.

E2327a, E2328a parts list with diagrams and quantities.

E2523, E2524a, E2525b parts list with diagrams and quantities.

E2581 parts list with diagrams and quantities.

E2815b OPT, E2816b parts list with diagrams and quantities.

H0274a, H0471a, H0855b, H0864-Ba parts list with diagrams and quantities.

E2269a, E2270b OPT parts list with diagrams and quantities.

E2329a, E2330 parts list with diagrams and quantities.

E2526b, E2530a, E2534b parts list with diagrams and quantities.

E2601a, E2601/1a, E2602, E2602/1 parts list with diagrams and quantities.

E2817a OPT, E2826 parts list with diagrams and quantities.

H0274a, H0471a, H0855b, H0864-Ba parts list with diagrams and quantities.

E2271a, E2272 OPT parts list with diagrams and quantities.

E2416-Ba parts list with diagrams and quantities.

E2535b, E2548a, E2564a parts list with diagrams and quantities.

E2712b, E2713b OPT, E2714a parts list with diagrams and quantities.

FP2155 parts list with diagrams and quantities.

H0274a, H0471a, H0855b, H0864-Ba parts list with diagrams and quantities.

- E2240b DIFF. SHAFT (H.T. DIFF.)
E2241a GASKET FOR DIFF. (H.T. DIFF.)
E2242b S6 O-RINGS SI (H.T. DIFF.)
E2243a DIFF. WASHER SET (H.T. DIFF.)
E2245-B CENTER DIFF. SET (46T)
E2250b SPUR GEAR 47T (H.T. DIFF.)
E2260a CENTER JOINT CUP
E2263b BEVEL GEAR 10T
E2264b CONICAL GEAR 46T
E2265 F/R DRIVE SHAFT (137)
E2266 F/R UNIVERSAL JOINT SET
E2267a SPUR GEAR 45T (H.T. DIFF.)
E2268a CENTER DRIVE SHAFT (88)
E2269a CENTER DRIVE SHAFT (161.5)
E2270b CLOSED WHEEL NUT
E2271a DIFF. GEAR 20T
E2272 F/R UNIVERSAL JOINT

- E2301b SERVO SAVER
E2303b RADIO PLATE MOUNT
E2306b SERVO SAVER PIPE
E2309b BRAKE DISC
E2310b AL. SERVO SAVER ARM
E2314b GASKET FOR DIFF. (H.T. DIFF.)
E2316a SERVO SAVER SPRING (HARD)
E2319a SERVO SAVER SHAFT
E2320a SERVO SAVER SPRING ADJUSTER
E2321a BRAKE CAM
E2322a SERVO SAVER SHAFT (ALUM)
E2324 BATTERY CONNECTOR HOLDER
E2325 ELECTRIC SWITCH HOLDER (FUTABA,SANWA)
E2326 ELECTRIC SWITCH HOLDER (Protek,G-Force)
E2327a BATTERY BOX (Large)
E2328a RECEIVER BOX
E2329a RADIO TRAY
E2330 BRAKE PAD SPRINGS
E2416-Ba STONE GUARD
E2419b DIFF. GEAR 20g
E2420a WEIGHT 40g

- E2421b FRONT BUMPER
E2422b REAR WING STAY
E2429a REAR WING MOUNT (+15)
E2430a AL. WING BUTTONS
E2431a REAR WING MOUNT PLATE CFRP
E2434a CHASSIS
E2504b DAMPER END BALL
E2505a STEERING PLATE
E2506a DAMPER BOOTS L
E2507 FRONT DAMPER SPRING φ1.5 L70/8.25T
E2510 FRONT DAMPER SPRING φ1.5 L70/7.5T
E2515 FRONT DAMPER SPRING φ1.6 L70/9.5T
E2516 FRONT DAMPER SPRING φ1.6 L70/9.25T
E2517 FRONT DAMPER SPRING φ1.6 L70/9.0T
E2518 FRONT DAMPER SPRING φ1.6 L70/8.75T
E2523 DIAPHRAGM
E2524a DAMPER PISTON (φ1.3/8H)
E2525b FRONT DAMPER CASE
E2530a AS-018 O-RINGS
E2534b DAMPER PISTON (φ1.35/5H)
E2535b DAMPER PISTON (φ1.2/8H)
E2548a REAR DAMPER CASE
E2564a SHOCK PIN

- E2568a REAR DAMPER STAY
E2569b DAMPER PISTON (φ1.3/6H)
E2571 REAR DAMPER STAY CFRP
E2572b EMULSION DAMPER CAP
E2573a EMULSION DAMPER CAP SEAL
E2574b OW2x4x0.5 AL. WASHER
E2577a FRONT SHOCK SET
E2579a FRONT SHOCK TOWER
E2580 REAR SHOCK SET
E2581 REAR SHOCK SPRING φ1.6 L86/9T
E2601a 5x10x4 NMB BEARINGS (2pcs.)
E2601/1a 5x10x4 NMB BEARINGS (10pcs.)
E2602 8x16x5 NMB BEARINGS (2pcs.)
E2602/1 8x16x5 NMB BEARINGS (10pcs.)
E2712b ENGINE MOUNT WASHER
E2713b ONE-PIECE ENGINE MOUNT
E2714a FLYWHEEL (4-shoe)

- E2715a FLYWHEEL NUT (4-shoe)
E2716a CLUTCH PINS (4-shoe)
E2717a CARBON CLUTCH SHOES (4-shoe)
E2718a AL. CLUTCH SHOES (4-shoe)
E2719a CLUTCH BELL 13T (4-shoe)
E2720a CLUTCH SPRINGS 0.9mm (4-shoe)
E2721a CLUTCH SPRINGS 0.95mm (4-shoe)
E2722 CLUTCH SPRINGS 1.0mm (4-shoe)
E2723a CLUTCH SET (4-shoe)
E2724 AL. CLUTCH SHOES 1dot (4-shoe)
E2725 AL. CLUTCH SHOES 2dot (4-shoe)
E2803b SERVO HORN
E2804b PIVOT BALL
E2805b LINKAGE PARTS
E2808a ANTENNA PIPE (150mm)
E2809b FUEL TANK CAP PULLER
E2815b AL. SERVO HORN TH SET
E2816b FUEL TANK
E2817a P2 O-RINGS
E2826 BRAKE SPRINGS
FP2155 FP01 TRUGGY BODY

PO402a 12 LOGO STICKER
PO403a 12 LOGO STICKER (METALLIC)
MUGEN SEIKI CO., LTD.
1395 Takane-Cho, Futatabi, Chiba 274-0817, Japan
表示価格はメーカー希望小売価格です。(税別価格)