## JX21-B07 プレラッピング エンジン 取扱説明書

このエンジンは、ラッピング(擦り合せ)済みとなっております。

走行においては、車体搭載後、スターターボックスでエンジンを始動させ、そのまま1タンク、ゆっくりなアクセレーションを繰り返し暖気してください(このときメインニードルを2分(時計の長針の動きを形容)ずつ締め込んで、アクセル全開で低速走行できるようにニードル調整を行ってください)。

2 タンク目からは、コースインして、1 タンクごとにメインニードルを 2 分ずつ締めてください。 ある程度のストレートスピードが出ても、コーナーの立ち上がり加速が鈍い時は、スローニードルを 2 分ずつ締めてください(このとき徐々にアイドリング回転数が変化する場合がありますので、アイドリング Adj.スクリューの調整も行ってください)。

コーナーからの加速があまりもたつかなくなり、ストレートもある程度速度が出るようになりましたら、そのニードルのまま 500cc 程度走行してください(トータル 1000~1500cc 程度)。

この状態で、慣らし運転は終了となりますが、絞り過ぎに注意して走行してください。

※ 注) 慣らし運転中は、燃料タンク 4 分の 3 程度の走行で給油してください。 ニードル調整の途中で、ストレートの途中でスピードが落ちる、アクセルを開けたときに息つきをする等の症状が起きた場合は、直前に調整したニードルを 5 分戻してください。

## Instruction Manual for JX21-B07 Pre-Lapping Engine

Congratulations on your purchase of JX21-B07 Pre-Lapping engine.

Start the engine installed on a car with the starter box, then let the engine idle and repeat slow acceleration for the warming operation of the engine until you have consumed 1 fuel tank. (During this process, turn the full speed needle clockwise (close) every 2 minutes to adjust the needle to be able to run at low speed at full throttle.)

On the second tank of fuel, try the car on the track. Turn the full speed needle 2 minutes clockwise (close) every 1 fuel tank. Turn the base speed needle every 2 minutes clockwise (close) if the acceleration out of corner is still slow even after the speed in a straight line reached to a certain level. (During this process, adjust the idling adj. screw to have the proper engine idling speed.)

Continue to run the car until you have consumed about 500 cc of fuel if the acceleration out of corner improved and the speed in a straight line reached to a certain level. (approx. 1000 – 1500 cc in total)

At this stage, the break-in process is complete. Make sure your engine is not running too lean.

\*\* Refuel after you have consumed about three-quarters tank of fuel during break-in process. If the engine slows down in the middle of the straight lane during the process of needle adjustment or does not accelerate smoothly when opening throttle, turn the needle 5 minutes counterclockwise (open).